GETTING STARTED WITH YOUR

DAF XB

Your DAF XB is equipped with advanced features to help you, the driver, get the best from your truck in terms of safety, comfort and efficiency.

This guide will help you get to grips with some of the key new features.

EXTERNAL FEATURES

Main Isolator (option)



Due to the increase in consumables on the truck, it is advisable to turn to the OFF position if away from the truck overnight or at weekends.



Critical Fluids



Oil level dipstick & filler (A) Coolant (B) and screenwash filler (C) points are located under the front grille, opened by simply pulling from the bottom.



Advanced Safety Features (Keep Them Clean)



There are various **Advanced Driver Assistance Systems** included on your DAF XB.

To obtain maximum functionality and limit any unnecessary warnings, it is good practice to give these a clean during your vehicle checks:

Front radars which sense objects such as vehicles and people (A)

Side radar sensing vehicles and pedestrians when turning (B)

Rear camera to give a clear view behind when reversing **(C)**



KFY SWITCHES & CONTROLS

Regeneration Inhibit Switch

)

The Diesel Particulate Filter (DPF) Switch inhibits Regeneration.

Press to inhibit and an LED will display. Press again to enable Regeneration.

This will default to 'enable' on 'key on'. Only use this switch when absolutely necessary, at fuel stations and alike.

A forced regeneration can be triggered **through the Vehicle Info Menu,**accessed using the RH

Steering Wheel Control.





Reverse Camera Switch



The Reverse Camera monitor, by default, is active when reverse gear is selected

and once deselected will go blank.

If you need to see behind you when reverse is NOT selected, press the switch where the monitor will display the camera view(s) momentarily.





Turn & Side Assist (Amber warning on A-Pillar)



Turn Assist Informs and warns the driver by a continuous amber light of the presence of pedestrians or cyclists next to the vehicle and is active below 18mph.

If a collision is imminent, the driver will be warned by the amber light blinking.

Side Assist informs and warns the driver of the presence of other road users in the adjacent lane at the vehicle's co-driver side when passing or turning and the light will blink when a collision is close. Side Assist is active from stationary.



Powerline Automatic Gearbox (option)



The automatic gearbox has Neutral, Drive and Reverse. Also, you can select Manoeuvring Mode. To engage the gears you must use the footbrake.

Be aware that when you take your foot off the brake pedal, the vehicle **will immediately move**, so it is good practice **when stationary at lights or crossings**, to apply the handbrake and select neutral.



LEFT HAND STEFRING WHEEL SWITCH

Cruise Control

Bring up your speed and press SET. Your setting is displayed in the dash. Cruise will remain until you press the brake pedal, a forward collision warning or you press OFF. You can adjust your speed setting up and down using +/-.

When re-engaging cruise control, it is good practice to bring the vehicle back up close to the set speed using the accelerator pedal and then pressing RES.



Speed Limiter



At your desired speed (above 16mph) press LIM and your speed will be displayed in the dash. To disengage press the OFF switch.

Should you need to exceed this set speed quickly (overtaking for **example)** depress the throttle pedal fully to override.



Exhaust Brake



Press to engage the exhaust brake and every time you take your foot off the throttle, the exhaust brake will engage.

Alternatively, when exhaust braking is not required, press the switch again to turn off. The Exhaust Brake icon will be displayed in the dash when active.



Adaptive Cruise Control



Press to bring up the distance setting and scroll to increase or decrease the distance between you and the vehicle in front.

Once setting Cruise (as above) the ACC will be engaged unless you have turned it off. Be aware that ACC remains at the last setting, so it's good

practice to check the setting before starting your day.





QUICK START TO THE DIGITAL DISPLAY

DISPLAY VIEWS INFO & SETTINGS

CLASSIC THEME





1126

1 1:26

THEMES:

There are two alternative appearances or 'themes' which can be selected in the Settings Menu.

Press the 'Menu' switch on the RH Steering Wheel Control (see image bottom of sheet), press to access the 'Vehicle Settings Menu' and scroll down to 'Display Settings' and 'enter', then scroll to 'Theme' where you can select your



The Classic Theme shows your favourites at the bottom and at the top on the

Favourites are simply selected using the Favourites switch on the RH **Steering Wheel Control:**

Press 'Favourites' to bring up - scroll to choose and press to enter.





ACCESSING THE DIGITAL DASH DISPLAY & INFORMATION

Key on, wait for the vehicle to do its self-checks.

Press the 'Menu' switch on the Right Hand Steering Wheel Control once. This will bring up the display main view. In the top left corner, you will see four icons; Bluetooth & Phone, Music, Vehicle Info and Settings. To switch between menus, press the menu switch and the menu you are in is highlighted.







This menu allows you to connect your phone and also displays your contact information once

To accept a call press the 'tick' switch on the RH Steering Wheel Control and to reject or end a call press the 'X' on the bottom of the Steering Wheel Control.




Music menu -



From the 'Phone' menu screen, press the menu switch once to move across to the

You can then scroll down to select your choice from radio, phone, music or a USB device. Once selected press to display the list and scroll down to select your preferred

You can also select a radio station and make it one of your favourites.



Vehicle Information menu



From the 'Music' menu screen, press the menu switch once to move across to the 'Vehicle Information' menu.

You can then scroll down to view the various systems; in this instance we are looking at tyre pressures. Once selected, press to display the information and act accordingly if there are any issues. This is worth doing as part of your vehicle checks.




Settings menu -



From the 'Vehicle Information' menu screen, press the menu switch once to move across to the 'Settings' menu.

You can then scroll down to view the various vehicle settings. When the setting you want to look at or change is highlighted, press to move across to the options and then scroll down. Press again to select the option where you can change the setting. With all menus, you

can press the return on the Steering Wheel Control once to go back or hold for two seconds to return to the main menu.



Favourites -



You can display various gauges and information on the dash such as fuel level, air pressure, drowsiness detection, DPF and many more by simply pressing the 'Favourites' switch on the RH Steering Wheel Control and scrolling through the options. Press to select and your next favourite will be displayed; and again scroll and press to select... There are three guages/info you can display.

INFORMATION VIEWS

There are four dash displays (on both Classic and Modern) to choose from. These views are displayed by using the scroll button.

- Complete driving overview screen
- Gauge view and favourites
- Night view with favourites

on the dash

Night view



RIGHT HAND STEERING WHEEL CONTROL

To view information and training on your DAF XB, including further information on many new safety features, **visit the DAF Trucks YouTube Channel.**

Alternatively, consult your driver handbook, **or contact your local DAF Dealer** who will be more than happy to help.



Contact Information:

DAF Trucks Ltd

Haddenham Business Park

Pegasus Way

Haddenham

HP17 8LJ

www.daf.co.uk

XB/TM/0225/

